

Games Mode

Arcade / party / waiting-room play. Walk up and hit a zone — no phone.

1	2	3
4	5	6
7	8	9

Catcher's view

HOW TO START

From the home screen, hit Zone 3 (purple). Then hit a game zone.

Zone 9 = Back from game select.

BOARD CONTROLS (EVERY MODE)

- Home: hit Zone 1 Sports · Zone 2 Therapy · Zone 3 Games.
- If asked: Zone 1 = solo / vs computer, Zone 2 = two players.
- Countdown: 3 red → 2 yellow → 1 green → GO.
- During play, Zone 9 is a normal target.
- After results: Zone 1 = Rematch, Zone 9 = Back.
- Quit mid-game: hit Zone 9 three times within 3 seconds.

GAMES IN THIS MODE

1 Tic Tac Toe

Solo vs computer or 2 players. Claim a zone. Three in a row wins.

2 Whack-a-Light

Hit the lit zone. Faster, competitive 30-second pace.

3 Around the Board

Hit zones 1→9 in order as fast as you can. 2P takes timed turns.

4 21

Blackjack-style. Hit a lit zone to add that number. Hold by waiting out the amber bar. Bust over 21.

5 Reflex Elimination

Solo. Hit the prompt before time is up. Windows get tighter.

6 Pattern Race

Board shows a sequence. Reproduce it against the clock.