

Sports Mode

Pitching drills and Tic Tac Toe. No app or phone required.

1	2	3
4	5	6
7	8	9

Catcher's view

HOW TO START

From the home screen, hit Zone 1 (blue). Then hit a game zone.

Page 1 uses zones 1–7. Zone 8 = More. Zone 9 = Back.

BOARD CONTROLS (EVERY MODE)

- Home: hit Zone 1 Sports · Zone 2 Therapy · Zone 3 Games.
- If asked: Zone 1 = solo / vs computer, Zone 2 = two players.
- Countdown: 3 red → 2 yellow → 1 green → GO.
- During play, Zone 9 is a normal target.
- After results: Zone 1 = Rematch, Zone 9 = Back.
- Quit mid-game: hit Zone 9 three times within 3 seconds.

GAMES IN THIS MODE

- 1 Tic Tac Toe**
Solo vs computer or 2 players. Claim a zone. Three in a row wins.
- 2 Free Play**
Solo. Any hit counts. Session ends after inactivity — no rematch screen.
- 3 First to 10**
2 players. Board calls a zone. First to 10 correct hits wins.
- 4 Accuracy**
Solo or 2P. Hit the called zone. Score is how many you paint.
- 5 Call a Zone**
Solo or 2P. Board lights the target. Hit it to score.
- 6 Corners Only**
Solo or 2P. Only zones 1, 3, 7, and 9 count.
- 7 Low & Away**
Solo or 2P. Work the low-away corner — keep painting that pocket.
- 8 More →**
Opens Sports page 2.
- 1 Streak (page 2)**
Solo or 2P. How many called zones in a row can you hit?
- 2 Timed 60 (page 2)**
Solo or 2P. Any zone scores. Race the 60-second clock.
- 8 More (page 2)**
Returns to Sports page 1.